

STRETCH TEST GUIDE FOR FX PU TRANSFERS



Recommended stretch test method

1 Wait 24 hours

Lay the garment flat on a table. Ensure the transfer is completely cooled and has rested for 24 hours before testing.

2 Hand Placement

Place your hands about 20 cm (8 inches) away from the edges of the design. Use a full-hand grip on the fabric (palm and fingers), not just pinching with two fingers. Avoid grabbing close to the print itself.

3 Stretch Gently ($\leq 40\%$)

Stretch the fabric evenly, without exceeding about 40% stretch of the original design.

4 Hold and Release

Hold the stretch for a few seconds at full extension, then gently release the fabric.



Common mistakes to avoid

Over-Stretching Do not pull the fabric beyond 40%.

Quick or forceful pulling Stretching should be slow and controlled.

Pinching near the design Do not grip right at the edge of the print.

Using fingernails or tools Do not pick or scratch the transfer edges. This does not reflect real-life use.